

Thank you for purchasing this CLARKE Right Angle Drill Attachment.

Please read this instruction leaflet thoroughly and follow the instructions carefully, in doing so you will ensure the safety of yourself and that of others around you, this will also ensure that the Right Angle Drill Attachment will give you long and satisfactory service.

Please keep these instructions in a safe place for future reference.

CLARKE GUARANTEE

This CLARKE product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which is was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

TECHNICAL SPECIFICATION

SETUP AND SAFETY PRECAUTIONS

- Insert and secure a drill bit into the chuck, attach a drill/drive to the drill attachment drive spindle.
- **NEVER** use with a drill in `hammer' mode.

Parts List

Chuck	
Chuck Securing Screw	SURAD1002
Chuck Key	SURAD1003
Chuck Removal Spanner	SURAD1004



For spare parts and servicing, please contact your nearest dealer, or CLARKE International on: 020 8988 7400 or email:

Parts@clarkeinternational.com

Service@clarkeinternational.com

CLARKE International, Hemnall Street, Epping, Essex, CM16 4LG